



Guidelines for tiling onto wooden panels

- Due to the inherent flexibility of these systems, Ezee tile recommends tiling only if the walls are firmly braced. Wooden panels need to be sanded down to remove all traces of polish, wax, etc. Clean the surface to remove any dust.
- The recommended adhesive for this application is **Ezee Tile Flex**. This is a ready mixed product and can be applied using a notched wall trowel as per the instruction on the bucket. Ensure that excess adhesive is removed from between the joints as the tiles are installed
- Allow for at least 24 hours for the adhesive to fully cure before grouting. Mix the 5 Kg bag of **Ezee Tile Waterproof Grout** with 1.5 litres of water and apply as per the instructions on the bag.

**This guideline only serves as a basic manual for the surface preparation, product selection and installation procedure for this type of application. Each installation needs to be assessed on merits and the products used and the procedures followed should be in accordance with the SABS code for the design and installation of ceramic tiles (SANS 10107:1997). For more detailed advice, please contact Ezee Tile.*